

INSTALL OR REMOVE ANCHOR GROMMETS

1. With the grommet in a vertical position facing you, flatten both sides down so they are against each other
2. Fold the grommet in half
3. Insert the grommet into the hole on the Anchor Mat
4. Press the grommet so one end is through the hole entirely
5. Twist the grommet inside the hole as it opens up into position
6. Both the top and bottom of the mat should have the large flat ends of the grommet laying against the fabric.
7. Plastic will soften over time or in the sun and relax in a flat position.
8. To Remove – Squeeze the exposed ends at the top and bottom of the mat and twist out of the hole.



9.

